

Food Safety Agent-Based-Simulator Facility (FS-ABS-F) Control Table			
ID	Type of Monitor or Controls Class	Functionality	Run Action or Example
<b>Run Controls:</b> <i>These are responsible for starting, pausing, and stopping the experiment</i>			
Setup	Button Control	<ul style="list-style-type: none"> <li>Push to Execute</li> <li>Set up variables and global</li> <li>Clear all</li> <li>Reset Time</li> </ul>	Momentarily
Next	Button Control	<ul style="list-style-type: none"> <li>Push to Execute</li> <li>Forward only one iteration</li> <li>Iteration length 0.33s</li> </ul>	Momentarily
Go	Button Control	<ul style="list-style-type: none"> <li>Push to Execute</li> <li>Perpetually Forward one iteration</li> <li>Push to stop</li> </ul>	Forever unless otherwise (set to stop after processing is complete when no agents in the facility)
<b>Input Mass:</b> <i>Future event scheduler (Our input arrivals are determined here)</i>			
Mass-to-Process	Slider Control	<ul style="list-style-type: none"> <li>Set the number of lettuce heads to process</li> <li>Mass unit is kg</li> <li>Range from 22 to 1620 kg</li> <li>Increment size is 0.5kg</li> </ul>	Once the set amount to process is reached our input arrivals stop coming
<b>Input contamination controls:</b> <i>Future event scheduler (controls introduce contamination into the system)</i>			
probability-Of-Contamination	Slider Control	<ul style="list-style-type: none"> <li>When lettuce arrives this probability setting will determine whether it's contaminated or not based on the set probability.</li> <li>Range from [ 0 to 1 ]</li> </ul>	For example, if the probability is set to 0.1 this means 1 in 10 of the incoming lettuce heads are contaminated
Contamination-Level	Slider Control	<ul style="list-style-type: none"> <li>After the lettuce head is determined to be contaminated based on <b>Probability-Of-Contamination</b> you would need a level of contamination which is this setting.</li> <li>Range from -12 to 6 logCFU/g</li> </ul>	For example, if 1 in 10 of the lettuce is said to be contaminated and the <b>contamination-level</b> is set to 2 logCFU/g, the contaminated lettuce will have 2 logCFU/g
SD	Slider Control	<ul style="list-style-type: none"> <li>The <b>Contamination-Level</b> is usually an estimated parameter with a mean and standard deviation, meaning this parameter is normally distributed.</li> <li>+/- logCFU/g</li> </ul>	For example, if the <b>Contamination-Level</b> is set to 2 logCFU/g and the SD is set to 0.5. The <b>contamination-level</b> will most likely be in this range 2 +/- 0.5 logCFU/g
iceberg-to-romaine	Slider Control	<ul style="list-style-type: none"> <li>Two breeds of lettuces iceberg and romaine</li> <li>Probability chance of lettuce being</li> </ul>	For example, if the slider is set 0 means all the arriving lettuces are ice-berg. If the slider is 0.2,

		romaine range from 0 to 1	80% of arriving is iceberg and 20 % is romaine.
<b>Partitioning:</b> <i>Lettuce and lettuces pieces will be cut into bits and more pieces</i>			
<i>Manual-Trim_#</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference 4.4.2.4 Manual Trim [ L2 ]</li> <li>Range from 0 to 3 partitions</li> <li>Number of lettuces pieces after partitioning <math>\text{Manual-Trim\_}\# + 1</math></li> </ul>	For example, if the setting is 1, the number of lettuce pieces after L2 is $1 + 1 = 2$
<i>Shred_#</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference 4.4.2.5 Shredding [ L3 ]</li> <li>Range from 0 to 3 partitions</li> <li>Number of lettuces pieces after partitioning <math>\text{Shred\_}\# + 1</math></li> </ul>	For example, if the setting is 3, the number of lettuce pieces after L3 is the pieces after L2 * (3 + 1 ) = 2 * 4 = 8
<b>Temperature Controls:</b> <i>These controls are responsible for temperature variation</i>			
<i>Set-Temperature</i>	Slider Control	<ul style="list-style-type: none"> <li>The <b>Set-Temperature</b> is the mean ambient temperature of the facility.</li> <li>Reference supplement equation 1 below</li> <li><math>\text{Set-Temperature} = \text{Set-T}</math></li> <li>Range from 7 to 32</li> </ul>	The average temperature of the room
<i>Temp-Offset</i>	Slider Control	<ul style="list-style-type: none"> <li>The <b>Temp-Offset</b> is the range parameter max and min.</li> <li>Reference supplement equation 1 below</li> <li><math>\text{Temp-Offset} = \text{Temp} - \text{Off}</math></li> <li>The range of Temp-Offset is from 0 to 3 because the range for the temperature in the Baranyi growth <b>missing equation number</b> model is from 4 to 35</li> </ul>	The range of temperature of the room
<i>Temp-Oscillation-Speed</i>	Slider Control	<ul style="list-style-type: none"> <li>The <b>Temp-Oscillation-Speed</b> is how quickly we desire the temperature to change.</li> </ul>	
Temperature Supplement Equation:  $\text{Current facility temperature} = \text{SetTemp} + \text{TempOffset} * \sin \left( \frac{\pi * \text{time}}{\text{TempOscSpd}} \right) \quad [1]$			
The temperature profile used in many dynamic models resembles some sinusoidal function reference <b>figure 4.8</b>			
<b>Equipment Surface Contamination:</b> <i>These controls are responsible for bacteria on equipment surfaces</i>			
<i>Cross-Contamination?</i>	Switch Control	<ul style="list-style-type: none"> <li>The process of cross-contamination <b>reference process chapter 3</b> can be turned on and off for the entire</li> </ul>	For example, if the switch is in the on position cross-contamination will take place, if

		process equipment.	off nothing will happen even if there is bacteria present on the equipment surface
<i>Allow-Initial-Contamination-of-patches</i>	Switch Control	<ul style="list-style-type: none"> <li>The choice to introduce contamination on the equipment before running as an initial condition.</li> <li>Initial condition Setup parameter</li> </ul>	Does not affect the cross-contamination process, if turned on slider controls: <i>L1-nc</i> , <i>L1-LC</i> , <i>L2-nc</i> , ....., <i>L4-LC</i> become active
<i>L1-nc</i>	Slider Control	<ul style="list-style-type: none"> <li>Depends on <i>Allow-Initial-Contamination-of-patches</i> switch in on position</li> <li>There are five L1 workers</li> <li>Range 0 to 5 workers</li> </ul>	For example, if <i>Allow-Initial-Contamination-of-patches</i> is turned on and <i>L1-nc</i> is set to 3. Three workers are randomly selected to be contaminated out of the five.
<i>L1-LC</i>	Slider Control	<ul style="list-style-type: none"> <li>Depends on <i>Allow-Initial-Contamination-of-patches</i> switch in on position and <i>L1-nc</i> greater than zero</li> <li>Range 0 to 4 logCFU/patch</li> </ul>	For example, if <i>L1-nc</i> is set to 3 and <i>L1-LC</i> is set to 2. Three of the five workers that are contaminated will be contaminated with 2 logCFU
<i>L2-nc</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-nc</i></li> <li>Range 0 to 15 in location L2</li> </ul>	Reference <i>L1-nc</i> except three patches will be randomly selected to be contaminated out of the fifteen.
<i>L2-LC</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-LC</i></li> </ul>	Reference <i>L1-LC</i>
<i>L3-nc</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-nc</i></li> <li>Range 0 to 36 in location L3</li> </ul>	Reference <i>L1-nc</i>
<i>L3-LC</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-LC</i></li> </ul>	Reference <i>L1-LC</i>
<i>L4-nc</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-nc</i></li> <li>Range 0 to 136 in location L4</li> </ul>	Reference <i>L1-nc</i>
<i>L4-LC</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>L1-LC</i></li> </ul>	Reference <i>L1-LC</i>
<b>Wash tank Controls: These controls are responsible for the wash-tank</b>			
<i>allow-transfer-in-water</i>	Switch Control	<ul style="list-style-type: none"> <li>The process of bacteria transfer in the wash tank <b>reference process chapter 3</b> can be turned on or off for the entire process duration.</li> </ul>	For example, if the switch is in the on position transfer will take place, if off nothing will happen even if there is bacteria present in lettuce. The links in the wash tank are left ineffective and there is no log reduction due to the water.
<i>Allow-Chlorination</i>	Switch Control	<ul style="list-style-type: none"> <li>The process of chlorination in the wash tank <b>reference process chapter 3</b> can be turned on or off for the</li> </ul>	For example, if the switch is in the on position transfer will take place, if off nothing will happen

		entire process duration.	even if there is bacteria present in lettuce. The links in the wash tank are left ineffective
<i>R-1</i>	Global Input	<ul style="list-style-type: none"> <li>The first dose of free chlorine at the beginning of the experiment usually 21 mg/L from Luo <b>reference process chapter 3</b>.</li> </ul>	
<i>R-2</i>	Global Input	<ul style="list-style-type: none"> <li>The second dose of free chlorine after 12 min usually 10 mg/L from Luo <b>reference process chapter 3</b>.</li> </ul>	
<i>R-3</i>	Global Input	<ul style="list-style-type: none"> <li>The second dose of free chlorine after 24 min usually 10 mg/L from Luo <b>reference process chapter 3</b>.</li> </ul>	
<i>Collect-TIT</i>	Switch Control	<ul style="list-style-type: none"> <li>Collect-TIT stands for Collect Time In Tank</li> <li>When this is switched on the time in tank for each lettuce head that has gone through the tank is save in a list from there the average time in tank is determined</li> </ul>	
<b><i>Misselenious: Experimental designs used for experiments and others</i></b>			
<i>Experiment-Buchholz</i>	Switch Control	<ul style="list-style-type: none"> <li>To activate simulation by Buccholz switch to on.</li> </ul>	22.5 kg lettuce heads first enter the system followed by 22.5 kg contaminated lettuces and finally 90 kg
<i>Contamination-Buchholz</i>	Slider Control	<ul style="list-style-type: none"> <li>Works similar to Contamination-Level but this will only apply to the 22.5 kg contaminated lettuce</li> <li>Values 2 4 6 logCFU/g</li> <li>Active when <i>Experiment-Buchholz</i> is on</li> </ul>	For example, if set to 2, the 22.5 kg contaminated lettuce heads in the Buchholz experiment will each have 2 logCFU/g
<i>Baseline</i>	Switch Control	<ul style="list-style-type: none"> <li>To activate simulation by Buccholz switch to on.</li> <li>Note you can't run Buchhols and Baseline at the same time program is designed to automatically switch to Buchholz if you press Setup and switch to Baseline if the user presses Go or Next</li> </ul>	
<i>Probability-BL</i>	Slider Control	<ul style="list-style-type: none"> <li>Works similar to <b><i>Probability-Of-Contamination</i></b> but this will only apply baseline experiment Will over-ride <b><i>Probability-Of-</i></b></li> </ul>	

		<b>Contamination</b> if <i>Baseline</i> is active/on	
<i>Contamination-BL</i>	Slider Control	<ul style="list-style-type: none"> <li>• Works similar to <b>Contamination-Level</b> but this will only apply to baseline experiment</li> <li>• Will over-ride <b>Contamination-Level</b> if <i>Baseline</i> is active/on</li> </ul>	
<i>ask-patches</i>	Slider Control	<ul style="list-style-type: none"> <li>• Works similar to L1-nc but in this case the number of equipment patches is from L1 to L4 the equipment surfaces before wash</li> <li>• Will over-ride <b>Allow-Initial-Contamination-of-patches</b> if <i>Baseline</i> is active/on</li> </ul>	For example, if it's set to 0.1 will mean 10% of the combined 192 patches from L1 to L4 will be randomly contaminated
<i>ask-patches-2</i>	Slider Control	<ul style="list-style-type: none"> <li>• Works similar to L1-nc but in this case the number of equipment patches is from L6 to L7 the equipment surfaces after wash</li> <li>• Will over-ride <b>Allow-Initial-Contamination-of-patches</b> if <i>Baseline</i> is active/on</li> </ul>	For example, if it's set to 0.1 will mean 10% of the combined 615 patches from L6 to L7 will be randomly contaminated
<i>p-L1-to-L4-lc</i>	Slider Control	<ul style="list-style-type: none"> <li>• Works similar to <i>L1-LC</i> this is the level of contamination on L1 to L4 surfaces.</li> </ul>	
<i>p-L6-to-L7-lc</i>	Slider Control	<ul style="list-style-type: none"> <li>• Works similar to <i>L1-LC</i> this is the level of contamination on L6 to L7 surfaces.</li> </ul>	
<i>p-sd-1</i>	Slider Control	<ul style="list-style-type: none"> <li>• This will introduce standard deviation on the level of contamination to <i>p-L1-to-L4-lc</i></li> </ul>	
<i>p-sd-2</i>	Slider Control	<ul style="list-style-type: none"> <li>• This will introduce standard deviation on the level of contamination to <i>p-L6-to-L7-lc</i></li> </ul>	
<i>Activate-Label</i>	Switch Control	<ul style="list-style-type: none"> <li>• If switched on the level of contamination in each agent will be shown.</li> </ul>	
<i>QC-Max-LogCFU</i>	Slider Control	<ul style="list-style-type: none"> <li>• When counting good bags and bad bags after packaging this is the threshold or quality control parameter with the minimum acceptable level of contamination</li> </ul>	
<i>Threshold</i>	Slider Control	<ul style="list-style-type: none"> <li>• The acceptable minimum level of safety in logCFU/g</li> </ul>	For example, if set to -2 logs means less than threshold 1/100

			cfu/g is considered safe
<i>Change-Size</i>	Slider Control	<ul style="list-style-type: none"> <li>We can double the size of the lettuce, it is only for aesthetics purposes</li> </ul>	

Food Safety Agent-Based-Simulator Storage (FS-ABS-S) Control Table			
ID	Type of Monitor or Controls Class	Functionality	Run Action or Example
<b>Run Controls:</b> These are responsible for starting, pausing, and stopping the storage and the facility simultaneously			
<i>Setup</i>	Button Control	<ul style="list-style-type: none"> <li>Reference Setup in FS-ABS-F</li> <li>In addition: <ul style="list-style-type: none"> <li>Starts the processing facility and the storage simultaneously</li> <li>Parent control: controls both models.</li> </ul> </li> </ul>	Momentarily
<i>Next</i>	Button Control	<ul style="list-style-type: none"> <li>Reference Next in FS-ABS-F</li> <li>In addition: <ul style="list-style-type: none"> <li>Forward one iteration storage and forward one iteration processing facility simultaneously</li> <li>Parent control: controls both models.</li> </ul> </li> </ul>	Momentarily
<i>Go</i>	Button Control	<ul style="list-style-type: none"> <li>Reference go in FS-ABS-F</li> </ul>	Reference go in FS-ABS-F
Temperature Controls: These controls are responsible for temperature variation in storage only			
<i>Set-Temperature</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>Set-Temperature</i> in FS-ABS-F</li> </ul>	Reference <i>Set-Temperature</i> in FS-ABS-F
<i>Temp-Offset</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>Temp-Offset</i> in FS-ABS-F</li> </ul>	Reference <i>Temp-Offset</i> in FS-ABS-F
<i>Temp-Oscillation-Speed</i>	Slider Control	<ul style="list-style-type: none"> <li>Reference <i>Temp-Oscillation-Speed</i> in FS-ABS-F</li> </ul>	Reference <i>Temp-Oscillation-Speed</i> in FS-ABS-F